



*Cover Batten Section slots with Blanking Tape (Code 33001)
for a distance of at least 600mm either side of the vent.



▲ Tilefix ▲ Specrite

▲ Estimator ▲ BIM

Visit marley.co.uk/technical-services
for a full suite of online tools to help with your
roof design, specification and fixing.

Feel free to talk to our experts at any time on
01283 722588.

Associated products & fixings

Anglia Aluminium Nail Pack
Code 30349 (500g)

Anglia SoloFix Tile Clips
Code 30444 (100 Pack)
Code 30434 (500 Pack)

DRAWING NUMBER

85518640

DRAWING REVISION

A

DRAWING TITLE

Ridge Terminals Extract Ventilation - Dry Fix

SCALE

1:10

Anglia

