



- Ridge Terminal (Code 198)
- Segmental Ridge Union (Code 413) or Mod/Seg Ridge Adaptor Union (Code 420)
- Ventilated Dry Ridge System
Low Profile Batten Section (Code 41101)
Steep Pitch Low Profile Batten Section (Code 41102)
- Wessex Filler Unit (Code 41901)
- Min.75mm Headlap
- Wessex Tile 420mm x 330mm (Code 106)
- Universal Underlays
Vapour Permeable (Code 33150)
Non-Breathable (Code 33145)
- JB Red Treated Battens Machine Graded to BS5534
38mm x 25mm (Rafters 400mm - 450mm)
50mm x 25mm (Rafters 450mm - 600mm)
- Wessex Solofix Tile Clip
- Plumbers Accessory Pack (Flexible pipe & adaptor) (Code 39090)

*Cover Batten Section slots with Blanking Tape (Code 33001) for a distance of at least 600mm either side of the vent.



Visit marley.co.uk/technical-services for a full suite of online tools to help with your roof design, specification and fixing.

Feel free to talk to our experts at any time on 01283 722588.

Associated products & fixings
Wessex SoloFix Tile Clips
Code 30442 (100 Pack)
Code 30432 (500 Pack)

DRAWING NUMBER

85510640

DRAWING TITLE

Ridge Terminals Extract Ventilation - Dry Fix

SCALE

1:10

DRAWING REVISION

A

Wessex

